


Pad Washing Guide.

Cleaning during the polishing process



Blow out polishing pads between polishing processes using compressed air.



Brush out lambskin or microfiber pads with a soft brush.



In case of component change or long polishing processes spray pads with degreaser (e.g. Sil 1:3), massage in and blow out with compressed air.

Cleaning after use, manual



Wet used pads with alkaline cleaner (e.g. Green Star 1:20), allow to react.



Rinse pads under running water (max. lukewarm).



Store on Velcro side to dry. Stretch lambswool pads on plate to prevent deformation.

Cleaning after application, by machine



Soak heavily soiled pads in a bucket of alkaline product (e.g. Green Star 1:20).



Wash pads in cold water, maximum 30/40°C / 86°/104°F.



Select gentle wash program (low rotation speed).



Use special detergent (e.g. microfiber detergent) which is free of fragrances, dyes, bleach, softeners and fillers.



Use liquid detergent. Powder may leave residue.



Do not wash with microfiber cloths or other fabrics.



Do not iron.

General notes

Do not dry pad in dryer.